



AUXSOL

WIN GREEN FUTURE TOGETHER

INSTALLATION OPERATION MANUAL

ASN-33~40TL

ASN-20~25TL-LV

AUXSOL

WIN GREEN FUTURE TOGETHER

Ningbo AUX Solar Technology Co., Ltd.

No.17 Fenglin Road, Cicheng Town,
Jiangbei District, Ningbo City, Zhejiang Province, China

✉ info@auxsol.com

🌐 www.auxsol.com

☎ +86 0574-8765 2201

Ningbo AUX Solar Technology Co., Ltd.



CONTENT

PREFACE

| | |
|---------------------------|---|
| Summary | 1 |
| Applicable products | 1 |
| Applicable staff | 1 |
| Symbol definition | 1 |

1 OPEN THE CARTON TO CHECK

| | |
|--|---|
| 1.1 Inspection before acceptance | 2 |
| 1.2 Packing list | 2 |
| 1.3 Storage | 3 |

2 SAFETY PRECAUTIONS

| | |
|----------------------------------|---|
| 2.1 General safety | 4 |
| 2.2 PV string safety | 4 |
| 2.3 Inverter safety | 5 |
| 2.4 Personnel requirements | 5 |

3 INTRODUCTION

| | |
|---------------------------------|---|
| 3.1 Products introduction | 6 |
| 3.2 Outlook introduction | 6 |
| 3.3 Dimension | 7 |
| 3.4 Display description | 7 |

PREFACE

4 APPLICATION

| | |
|------------------------------------|----|
| 4.1 Grid form | 18 |
| 4.2 Application scenario | 19 |
| 4.3 Application mode | 20 |
| 4.4 Function characteristics | 20 |

5 INSTALLATION

| | |
|-------------------------------------|----|
| 5.1 Installation requirements | 21 |
| 5.2 Installation of inverter | 24 |
| 5.3 Electrical connection | 25 |

6 EQUIPMENT COMMISSIONING AND MAINTENANCE

| | |
|---|----|
| 6.1 Check before power-on | 34 |
| 6.2 Power on the equipment | 34 |
| 6.3 Set inverter parameters via APP | 35 |
| 6.4 Power off the equipment | 35 |
| 6.5 Equipment removal | 36 |
| 6.6 Equipment scrapping | 36 |
| 6.7 Trouble shooting | 36 |
| 6.8 Regular maintenance | 43 |

7 TECHNICAL PARAMETER

44

Summary

This document mainly introduces the installation, electrical connection, adjustment, maintenance and troubleshooting methods of ASN series three phase on grid solar inverter. Before installing and using the inverter, please read this manual carefully to understand the safety information and get familiar with the functions and characteristics of the inverter. The document may be updated from time to time. Please obtain the latest version of the information and other product information from the official website.

Applicable products

This document is applicable to the following ASN series three phase on grid inverter:

ASN-33~40TL

ASN-20~25TL-LV

Applicable staff

It is only applicable to professionals who are familiar with local regulations and standards and electrical system, have received professional training and are familiar with the relevant knowledge of the product.

Symbol definition

To better use this manual, the following symbols are used to highlight important information. Please read the symbols and instructions carefully.



Danger:

Indicates a highly potential danger that, if not avoided, could result in death or serious injury to personnel.



Warning:

Indicates a moderate potential hazard, which could lead to death or serious injury if not avoided.



Watch out:

Indicates a low level of potential danger that, if not avoided, may result in moderate or mild injury to personnel.



Watch out:

Emphasizing and supplementing the content may also provide tips or tricks for optimizing product usage, which can help you solve a problem or save you time.

1 OPEN THE CARTON TO CHECK

1.1 Inspection before acceptance

Before signing for the product, please carefully check the following contents:


- Check the outer packaging for any damage, such as deformation, holes, cracks, or other signs that may cause damage to the equipment inside the packaging. If there is any damage, do not open the packaging and contact your dealer.
- Check if the inverter model is correct. If there is any discrepancy, do not open the packaging and contact your dealer.
- Check whether the type and quantity of delivered items are correct, and whether there is any damage to the appearance. If there is any damage, please contact your dealer.

1.2 Packing list



Watch out:

- The number of PV DC input terminals matches the number of inverter DC input terminals.
- The datalogger and electricity meter kit are provided as optional, please refer to the actual situation.



| No. | Description | Model | Unit | QTY | Remark |
|-----|------------------------------------|---------------|------|-----|----------|
| 1 | Inverter | | pcs | 1 | |
| 2 | User manual | | pcs | 1 | |
| 3 | Quick installation manual | | pcs | 1 | |
| 4 | Combination screws | M4 | pcs | 6 | |
| 5 | Combination screws | M5 | pcs | 2 | |
| 6 | Bolt+nut+spring washer+flat washer | M10 | set | 2 | |
| 7 | Hanger | | pcs | 1 | |
| 8 | PV terminals (+, -) | | pcs | * | |
| 9 | Datalogger | | pcs | 1 | |
| 10 | Terminals | SC 25-6 | pcs | 5 | |
| 11 | Inspection report | | pcs | 1 | |
| 12 | AC terminal waterproof cover | | pcs | 1 | |
| 13 | Waterproof terminal | | pcs | 1 | |
| 14 | Output signal connector | C-PVS-PA16-02 | pcs | 1 | optional |
| 15 | Meter kit | | pcs | 1 | optional |
| 16 | CT | | set | 1 | optional |

* The number of PV terminals allocated corresponds to the number of specific inverter terminals.

1.3 Storage

If the inverter is not put into use immediately, please store it according to the following requirements:

- Make sure that the outer packing box is not removed.
- Make sure that the storage temperature is always - 40 °C~+70 °C and the storage relative humidity is always 0~100% without condensation.
- Make sure the inverter stacking height and direction are placed according to the label on the packing box.
- Make sure there is no risk of toppling the inverter after stacking.
- Regular inspection is required during storage. If the package is damaged due to insect and rat bite, the packaging materials shall be replaced in time.
- The inverter shall be put into use after being stored for a long time and inspected and confirmed by professionals.

2 SAFETY PRECAUTIONS

The safety precautions contained in this document must always be observed when operating the equipment.



Watch out:

The inverter has been designed and tested in strict accordance with safety regulations, but as electrical equipment, the relevant safety instructions must be observed before any operation on the equipment. Improper operation may lead to serious injury or property damage.

2.1 General safety



Watch out:

- Due to product version upgrading or other reasons, the document content will be updated from time to time. If there is no special agreement, the document content cannot replace the safety precautions in the product label. All descriptions in this document are for guidance only.
- Please read this document carefully for products and precautions before installing the equipment. Professional and qualified electrical technicians who shall be familiar with the relevant standards and safety specifications of the project site must carry out all equipment operations.
- Insulation tools and personal protective equipment shall be used to ensure personal safety during inverter operation. Electrostatic gloves, wrist strap and antistatic clothing shall be worn when contacting with electronic devices to protect the inverter from electrostatic damage.
- Equipment damage or personal injury caused by inverter not installed, used or configured in accordance with the requirements of this document or corresponding user manual is not within the responsibility scope of equipment manufacturer.

2.2 PV string safety



Danger:

- Please use the DC wiring terminals provided with the box to connect the inverter DC cable. If other types of DC wiring terminals are used, serious consequences may be caused, and the equipment damage caused thereby is not within the scope of the equipment manufacturer.
- The solar array (solar panel) will have DC high voltage.



Warning:

- PV panel used with inverters must have IEC 61730 class A rating or other equivalent standard class.
- Make sure good grounding of component frame and support system.
- Do not ground the PV array positive (+) or negative (-) as this may cause serious damage to the inverter.
- Make sure that the DC cables are firmly connected without looseness after connection.
- Use a multimeter to measure the positive and negative electrodes of the DC cable. Make sure that the positive and negative electrodes are correct, no reverse connection occurs and the voltage is within the allowable range.
- Do not connect the same PV string to multiple inverters, or the inverter may be damaged.
- In order to reduce the risk of fire, the inverter connected circuit requires an overcurrent protection device (OCPD). DC OCPD shall be installed according to local requirements. All PV power supplies and circuit conductors shall have disconnect connections in accordance with NEC Article 690, Part II.

2.3 Inverter safety



Danger:

- Please connect the inverter AC cable with the AC wiring terminals provided with the box. If other types of AC wiring terminals are used, serious consequences may be caused, and the equipment damage caused thereby is not within the scope of the equipment manufacturer.
- Danger of electric shock. There are no serviceable parts inside the machine. Please do not disassemble it. Please obtain service from qualified and recognized service technicians.



Warning:

- Make sure that the voltage and frequency of the grid connection access point meet the inverter grid connection specifications.
- It is recommended to add circuit breaker or fuse and other protective devices at the AC side of the inverter, and the specification of the protective device shall be 1.25 times greater than the maximum AC output current of the inverter.
- The protective ground wire of inverter must be firmly connected to make sure that the impedance between neutral wire and ground wire is less than 10 Ω.
- Copper core cable is recommended for AC output cable.

Identifications on inverter box are as follows:



Danger of high voltage. There is high voltage when the inverter is operating. When operating the inverter, make sure the inverter is powered off.



Time delay discharge. Wait for 5 minutes after the equipment is powered off until the equipment is fully discharged.



Please read the product manual carefully before operating the equipment.



Potential hazards after equipment operation. Please take protective measures during operation.



There is high temperature on the inverter surface, so do not touch it when the equipment is running, otherwise, it may cause scald.



Connection point of protective earthing wire.



CE symbol



The equipment shall not be treated as domestic garbage. Please treat the equipment according to local laws and regulations or send it back to the equipment manufacturer.

2.4 Personnel requirements



Watch out:


- Personnel responsible for installing and maintaining equipment must first undergo strict training, understand various safety precautions, and master the correct operating methods.
- Only qualified professionals or trained personnel are allowed to install, operate, maintain, or replace equipment or components.

3 INTRODUCTION

3.1 Products introduction

The ASN series three phase on grid inverter integrates the energy management system in the PV system to control and optimize the energy flow, adapt to the requirements of the smart grid and output the power generated in the PV system to the utility/national grid.


3.2 Outlook introduction



The pictures in the manual are only schematic drawings. The product and optional parts are subject to the actual product.


| No. | Component | Description |
|-----|---|--|
| 1 | LED indicator light | Indicates the working status of the inverter |
| 2 | DC switch | Control DC input on or off (warning: this switch does not have breaking capacity and is prohibited to operate when the machine is running) |
| 3 | PV DC port | Connect PV module with PV wiring connector |
| 4 | Meter communication port /RS485 port /DRM port (optional) | Smart meters/sunspec communication can be connected via RS485 / Demand response interface |
| 5 | Communication module port | The communication module can be connected via RS485, supporting optional communication modules such as bluetooth, Wi-Fi, 4G and LAN |
| 6 | Utility/national grid power interface (black) | Connect AC Utility/national grid supply |

3.3 Dimension




3.4 Display description

3.4.1 LED1 (Optional)




| Indicator diagram | Status | Description |
|----------------------|-----------------|---|
| Bluetooth map | Off | Bluetooth not connected |
| | Always on | Bluetooth connected |
| WiFi map | Off | No communication at the communication module port |
| | Always on | Normal communication of communication module port |
| E-day | On | At this time, the central digital area displays the daily PV power generation |
| Pac | On | At this time, the central digital area displays the real-time grid power |
| Digital display tube | On | Display the specific value of this parameter |
| Light strip | Red always on | Fault mode (corresponding fault code displayed in the central digital area) |
| | Yellow flashes | Alarm mode |
| | Green always on | Normal operation mode |
| | Green flashes | Standby mode |

3.4.2 LED2 (Optional)




| Indicator diagram | Status | Description |
|-------------------|-----------------|-----------------------|
| Light strip | Red always on | Fault mode |
| | Yellow flashes | Alarm mode |
| | Green always on | Normal operation mode |
| | Green flashes | Standby mode |

3.4.3 LED3 (Optional)



| Indicator diagram | Status | Description |
|-------------------|------------------|--|
| PWR | Green always on | The product are connected the grid normally |
| | Green flashes | Product standby, startup and self-test |
| | Extinguish | The product is disconnected from the power grid |
| COM | Yellow always on | The product is properly connected to the monitoring device |
| | Yellow flashes | Product and monitoring equipment for date transmission |
| | Extinguish | The communication is abnormal or no date is transmitted |
| ERR | Red always on | System failure shutdown |
| | Red flashes | System alarm |
| | Extinguish | System fault clearance |

3.4.4 LCD (Optional)



The LCD screen display module includes a display screen and two touch buttons on the front panel of the inverter, which shows the following information:

- Inverter operation status and data.
- Alarm messages and fault indications.

You can also get information via WiFi / GPRS.

3.4.5 LCD Operation Menu

3.4.5.1 Button

The LCD screen display module has two touch buttons.

Touch buttons are as follows:

| Button mode | Meaning |
|--------------------------------|---------|
| Touch button 1 | UP |
| Touch button 2 | DOWN |
| Press and hold button 1 for 2s | BACK |
| Press and hold button 2 for 2s | ENTER |

3.4.5.2 LED display light

LED display light has red, green, yellow three colors.

LED display light display effect is steady on, off and blinking (on 0.5s off 0.5s), as described in the following table:

| Device status | LED | Priority |
|------------------|--|----------|
| Upgrades | Red, green and yellow flash alternately. | 1 |
| Breakdown | Red light steady on | 2 |
| Alarm | Yellow light flashing | 3 |
| Power generation | Green light steady on | 4 |
| Standby | Green light flashing | 5 |


Remarks: Priority 1 is the highest, and it decreases in turn.

3.4.6 LCD work menu

The LCD is located on the front panel of the inverter, which shows the following information:

- Inverter operation status and data.
- Alarm messages and fault indications.

During normal operation, the display alternately shows the power and the operation status for 5 seconds. The LCD screens can also be manually scrolled by pressing UP and DOWN buttons. Press and hold button 2 for 2s gives access to the main menu or press and hold button 1 for 2s calls back to the previous menu.



3.4.7 Main menu

There are 7 submenus in the main menu:

- Current Data
- History Error
- History Elec
- System Param
- Contrl Param
- Regulation Para
- Device Info

3.4.8 Current data

The AUX ASN series single-phase inverter main menu provides access to operating data and information. Select Current Data from the menu to display the information and scroll up or down.

| No. | Display | Description |
|-----|-----------------------|--|
| 1 | Mode Generate | Display the current operating mode of inverter |
| 2 | GRID VOLT 220.0V | Display grid voltage value |
| 3 | GRID P 4.98KW | Display the instant output power value |
| 4 | GRID FREQ 50.00HZ | Display grid frequency value |
| 5 | E_DAY 25.78kWh | Total Elec on that day |
| 6 | E_TOTAL 8458.57kWh | Total Elec |
| 7 | PV1 VOLT 250.5V | Display PV1 voltage value |
| 8 | PV2 VOLT 260.8V | Display PV2 voltage value |
| 9 | PV1 CUR 10.7A | Display PV1 current value |
| 10 | PV2 CUR 10.5A | Display PV2 current value |

3.4.9 History error

| | |
|---|---|
| 2022-03-04 19:33:39 10. IsolationAlarm | LCD display shows the latest 31 alarm messages. Press UP/DOWN to manually scroll through the screen. Press and hold button 1 for 2s to the previous menu. |
|---|---|

3.4.10 History elec

Select the date of daily generation

| | |
|------------------------|--|
| 2022-03-05 23.51kWh | 1. His Daily Elec This function is used to view the generated energy on the selected date. Press UP/DOWN to change the date. |
|------------------------|--|

Select the month of monthly generation

| | |
|----------------------|--|
| 2022-03 223.51kWh | 2. His Month Elec This function is used to view the energy production for the selected month. Press UP/DOWN to change the month. |
|----------------------|--|

Select the year of annual energy production

| | |
|--------------------|---|
| 2022 1323.51kWh | 3. His Year Elec This function is used to view the energy production for the selected year. Press UP/DOWN to change the year. |
|--------------------|---|

3.4.11 System param

3.4.11.1 Set address


This function is used to set the address when multiple inverters are connected to a single monitor. The address number can be assigned from "01" to "10".

| | |
|-------------------|--|
| 1.Comm Ad dr 1 | The default address number of AUX ASN series single-phase inverter is "01". Press the UP/ DOWN buttons to set the address. Press and hold button 2 for 2s to save the settings. Press and hold button 1 for 2s to cancel the change and return to the previous menu. |
|-------------------|--|

3.4.11.2 Selecting regulation

This function is used to select the reference regulation for the grid.

| | |
|---------------------|--|
| 2.Regulation CQC | Press UP/DOWN to select the regulation. (CQC,Brazil,EN_50549,IEC61727_50,IEC61727_60,Wide_Range_50,Wide_Range_60,Spain,Poland). |
|---------------------|--|

| | |
|---|--|
|  | Attention: This function is for technical personnel only. For different countries, grid regulations need to be set differently according to local requirements. If in doubt, consult your AUX technician. Below is the setting range for "User-Def". The following are user-defined setting ranges. With this function the limits can be changed manually. (CQC,Brazil,EN_50549,IEC61727_50,IEC61727_60,Wide_Range_50,Wide_Range_60,Spain,Poland). |
|---|--|

3.4.11.3 Set language

| | |
|-----------------------|---|
| 3.Language English | Press UP/ DOWN to set the language. Press and hold button 2 for 2s to save the settings. Press and hold button 1 for 2s to cancel the change and return to the previous menu. |
|-----------------------|---|


3.4.11.4 Set time

This function allows to set time and date. When this function is selected, the LCD displays the following <Time Set>

| | | | |
|-----------------------------------|------------|-------------------|------------|
| 4.Time Set 2023/04/24 11:01:03 | Set Time | Date-Year 2023 | Set Year |
| Date-Month 4 | Set Month | Date-Day 24 | Set Day |
| Time-Hour 11 | Set Hour | Time-Minute 1 | Set Minute |
| Time-Second 3 | Set Second | | |

Press UP/ DOWN to set the time and data. Press and hold button 2 for 2s to save the settings and press and hold button 1 for 2s to return to the previous menu.

3.4.12 Control param

| | |
|---|--|
|  | Attention: Only fully qualified and approved technicians shall enter the area. Password is required to enter the menu "Control Param". Select "Control Param" on the Main Menu.The screen will require the password: |
|---|--|

| | |
|------------------|--|
| Password 0000 | The default password is"1020". Please press DOWN to move the cursor and press UP to select the number. After enter the correct password the main menu will display a screen and be able to access to the following information: 1. remote control 2. clear His.error 3. restore factory |
|------------------|--|

3.4.12.1 Remote control

This function is used to start or stop AUX single-phase inverter power generation.

| | |
|----------------------------|---|
| Remote control Power on | Press UP/DOWN to manually scroll the screen. Press and hold button 2 for 2s to save the setting. Press and hold button 1 for 2s to return to the previous menu. |
|----------------------------|---|

3.4.12.2 Clear his.error

This function is used to clear the fault record.


| | |
|-------------------------------------|--|
| His Elec Clear? Cancel affirm | Press and hold button 2 for 2s to save the setting , Press and hold button 1 for 2s to return the previous menu. |
|-------------------------------------|--|

3.4.12.3 Restore factory

Restore factory settings to set special settings for all items to default values. The screen shows as below:

| | |
|------------------------------|---|
| Restore? Cancel affirm | Press and hold button 2 for 2s to save the setting. Press and hold button 1 for 2s to return the previous menu. |
|------------------------------|---|

3.4.13 Regulation para

| | |
|---|---|
|  | <p>Attention:</p> <p>Only fully qualified and approved technicians shall enter the area. Password required to enter the menu "Regulation Para". Select "Regulation Para" to enter the main menu. The password required on the screen is:</p> |
|---|---|

| | | |
|---|------------------|--|
| <table border="1"> <tr> <td>Password 0000</td> </tr> </table> | Password 0000 | <p>The default password is"1020". Please press DOWN to move the cursor, press UP to select numbers. When the correct password is entered, the main menu displays an interface to access the following information:</p> |
| Password 0000 | | |

| No. | Display | Description |
|-----|----------------------------|--|
| 1 | GridOverVolt_1 110% | Display the primary over voltage protection value of power grid |
| 2 | GridOverVolt_T1 1000ms | Display the primary over voltage protection time of power grid |
| 3 | GridOverVolt_2 135% | Display the secondary over voltage protection value of power grid |
| 4 | GridOverVolt_T2 40ms | Display the secondary over voltage protection time of power grid |
| 5 | GridOverVolt_3 135% | Display the three-level over voltage protection value of power grid |
| 6 | GridOverVolt_T3 40ms | Display the three-level over voltage protection time of power grid |
| 7 | GridUnderVolt_1 85% | Display the primary under voltage protection value of power grid |
| 8 | GridUnderVolt_T1 1000ms | Display the primary under voltage protection time of power grid |
| 9 | GridUnderVolt_2 50% | Display the secondary under voltage protection value of power grid |
| 10 | GridUnderVolt_T2 80ms | Display the secondary under voltage protection time of power grid |
| 11 | GridUnderVolt_3 20% | Display the three-level under voltage protection value of power grid |
| 12 | GridUnderVolt_T3 40ms | Display the three-level under voltage protection time of power grid |
| 13 | GridOverVFreq_1 50.50HZ | Display the primary over-frequency protection value of power grid |

| No. | Display | Description |
|-----|----------------------------|--|
| 14 | GridOverVFreq_T1 180ms | Display the primary over-frequency protection time of power grid |
| 15 | GridOverVFreq_2 55.00HZ | Display the secondary over-frequency protection value of power grid |
| 16 | GridOverVFreq_T2 140ms | Display the secondary over-frequency protection time of power grid |
| 17 | GridOverVFreq_3 55.00HZ | Display the three-level over-frequency protection value of power grid |
| 18 | GridOverVFreq_T3 140ms | Display the three-level over-frequency protection time of power grid |
| 19 | GridUnderFreq_1 47.50HZ | Display the primary under-frequency protection value of power grid |
| 20 | GridUnderFreq_T1 180ms | Display the primary under-frequency protection time of power grid |
| 21 | GridUnderFreq_2 45.00HZ | Display the secondary under-frequency protection value of power grid |
| 22 | GridUnderFreq_T2 140ms | Display the secondary under-frequency protection time of power grid |
| 23 | GridUnderFreq_3 45.00HZ | Display the three-level under-frequency protection value of power grid |
| 24 | GridUnderFreq_T3 20ms | Display the three-level under-frequency protection time of power grid |
| 25 | Restart Time 60s | Display start time |
| 26 | Reconnected Time 60s | Display reconnection time |

Press UP/DOWN to manually scroll the screen. Press and hold button 2 for 2s to enter the parameter modification interface, than press DOWN to move the cursor, press UP to select numbers, press and hold button 2 for 2s to save the settings, press and hold button 1 for 2s to cancel the change and return to the previous menu.

3.4.14 Device info

3.4.14.1 Software version

| | |
|-----------------------------|--|
| 1.Software Version A1259 | This screen displays the inverter software version number. |
|-----------------------------|--|

3.4.14.2 Rated power


| | |
|------------------------|---|
| 2.Rated Power 10 kW | The screen displays the inverter's rated power. |
|------------------------|---|

3.4.14.3 SN number

| | |
|-----------------------------------|---|
| 3.SN Number ASN-40TL2408120022 | The screen shows the SN Number of the inverter. |
|-----------------------------------|---|

4 APPLICATION


4.1 Grid form



4.2 Application scenario

Warning:

- PV systems are not suitable for connecting devices that rely on stable power supply, such as life-sustaining medical equipment. Please ensure that the power outage of the system does not cause personal injury.
- When the inverter is protected for a single time, the inverter can be automatically restarted.



| No. | Component | Description |
|-----|--------------------|---|
| 1 | PV string assembly | PV string consists of PV modules connected in series |
| 2 | Inverter | ASN series on grid inverter |
| 3 | AC circuit breaker | Used for inverter and load protection and for interrupting AC supply during maintenance |
| 4 | Smart meter | Optional |


AC circuit breaker

| Model | Voltage(Vac) | Current(A) |
|-------------|--------------|------------|
| ASN-33TL | ≥400 | 100 |
| ASN-36TL | ≥400 | 100 |
| ASN-40TL | ≥400 | 100 |
| ASN-20TL-LV | ≥400 | 100 |
| ASN-25TL-LV | ≥400 | 100 |

4.3 Application mode

4.3.1 Full grid connection

If no load is required, all energy of the inverter can be supplied to the utility/national grid to realize full grid connection of power generation.



4.4 Function characteristics

4.4.1 Power derating

The inverter will automatically reduce the output power when the operating environment is not ideal.

The following factors may cause power derating, so please try to avoid them during use:

- Unfavorable environmental conditions such as direct sunlight, high temperatures, etc.
- The inverter's output power percentage has been limited by the app or web-end settings.
- Variation with grid voltage frequency.
- High input voltage.
- High input current value.

5 INSTALLATION


5.1 Installation requirements

5.1.1 Environmental requirements

- The protection class of inverter is IP66, which can be installed indoor and outdoor.
- Equipment shall not be installed in flammable, explosive and corrosive environment.
- The installation position shall be kept away from the accessible range of children and the position easy to be touched. High temperatures may be present on the surface when the equipment is in operation to prevent burns.
- The installation position shall avoid the water pipe and cable in the wall to avoid danger during punching.
- The inverter shall avoid salt fog areas and installation environments such as sunshine, rain and snow. It is recommended to install the inverter in a sheltered installation position. If necessary, a sunshade can be erected.
- When installing the inverter, certain space shall be reserved around the inverter to ensure sufficient installation and heat dissipation space.
- Under the installation scenario of multiple inverters, when the space is sufficient, the installation mode of "straight line" is recommended, When the space is insufficient, it is recommended to install the product in a zig-zag manner. It is not recommended to install multiple inverters by overlapping.
- The installation height of the equipment shall be convenient for operation and maintenance, ensure that the equipment indicator lights, all labels are easy to see, and the terminal blocks are easy to operate.
- The inverter is installed at an altitude lower than the maximum working altitude of 4000m.
- Keep away from strong magnetic field environment to avoid electromagnetic interference. If there is a radio station near the installation location or wireless communication equipment below 30MHz, please install the equipment according to the following requirements:

Ferrite core with multi-circle winding or low-pass EMI filter at inverter DC input or AC output.

The distance between inverter and wireless electromagnetic interference equipment exceeds 30m.




5.1.2 Carrier requirements

- Installation carriers must not be flammable and must be fire resistant.
- Please make sure that the mounting carrier is solid and reliable and can bear the weight of inverter.
- The equipment will vibrate during operation, so do not install it on the carrier with poor sound insulation, so as to avoid disturbance to residents in the living area caused by the noise generated by the equipment during operation.

5.1.3 Installation angle requirements

- Recommended inverter installation angle: vertical or pitching $\leq 15^\circ$.
- Do not invert, tilt forward, tilt backward beyond the angle and install the inverter horizontally.



5.1.4 Installation tool requirements

The following installation tools are recommended for installation. Other auxiliary tools can be used on site if necessary.

| | | | | |
|--|---|--|---|--|
|  Percussion drill |  Sockets tool box |  Torque screw driver |  Diagonal pliers |  Wire stripper |
|  Crimping pliers |  Pressing terminal crimping plier |  Hydraulic tongs |  Wire cutter |  Multimeter (Vdc range 1500V) |
|  Rubber hammer |  Vacuum cleaner |  Tape measure |  Levelling instrument |  Electrician's knife |
|  Heat shrinkable sleeve |  Air heater |  Cable ties |  Goggles |  Insulating gloves |
|  Protective gloves |  Respirator |  Protective shoes | | |

5.2 Installation of inverter


Watch out:

- Transportation, turnover, installation and other operations must meet the requirements of national and regional laws and regulations and relevant standards.
- Please equip corresponding personnel according to the weight of the equipment to prevent the equipment from exceeding the weight range that can be handled by human body and damaging personnel.
- Wear safety gloves to avoid injury.
- Please make sure that the equipment is balanced during handling to avoid dropping.




Watch out:

- When drilling holes, make sure that the drilling position is kept away from water pipes, cables, etc. in the wall to avoid danger.
- Wear goggles and dust mask when punching to avoid dust inhalation into respiratory tract or into eyes.
- Make sure that the inverter is securely installed to prevent injuries from falling.
- Need to bring own expansion bolts for wall mounting.



Bracket mounting

Wall mounting



5.3 Electrical connection

5.3.1 Safety precautions

Danger:

- Specifications of all operation, cables and components used in electrical connection shall comply with local laws and regulations.
- Before electrical connection, please disconnect the DC switch and AC output switch of inverter to make sure that the equipment is powered off. It is strictly forbidden to operate with electricity, otherwise, electric shock and other hazards may occur.
- Cables of the same type shall be bound together and arranged separately from cables of different types. It is forbidden to wind or cross cables.
- If the cable bears too much tension, it may lead to poor wiring. When wiring, please reserve a certain length of the cable before connecting to the inverter wiring port.
- When crimping the connecting terminal, please make sure that the conductor part of the cable is fully contacted with the connecting terminal, and do not crimp the cable insulation skin together with the connecting terminal, otherwise, the equipment may be unable to operate, or the inverter terminal block may be damaged due to heating due to unreliable connection after operation.



Watch out:


- When making electrical connection, please wear safety shoes, protective gloves, insulating gloves and other personal protective equipment as required.
- Only professionals are allowed to carry out operations related to electrical connection.



5.3.2 Connect protective earth wire

Warning:

- The protective grounding of the crate shell cannot replace the protective grounding wire of the AC output port. When wiring, ensure that the protective grounding wires at the two places are reliably connected.
- In case of multiple inverters, make sure that the protective earthing point of all inverter crate enclosures is equipotentially connected.
- To improve the corrosion resistance of the terminal, it is recommended to apply silicone or paint on the external of the grounding terminal for protection after the connection and installation of the protective ground wire.
- Please prepare the protective ground wire, and the recommended specification:
Type: Outdoor single-core copper wire
Conductor sectional area: 4-16mm² (Phase cable diameter/2)



5.3.3 Connect PV input cable

Danger:

- Do not connect the same PV string to multiple inverters, otherwise the inverter may be damaged.
- Please make sure that the maximum short circuit current and maximum input voltage of each MPPT are within the allowable range of the inverter.
- Please make sure that the positive electrode of the PV string is connected to the PV port+of the inverter, and the negative electrode of the PV string is connected to the PV port - of the inverter.
- Please prepare your own PV input cable. Recommended specification:
Type: Outdoor PV multi-core copper wire
conductor cross-section: 4-6mm² (12 - 10AWG)
Outer diameter of conductor insulation layer: φ3~7mm




Warning:

- PV string output does not support grounding. Before connecting PV string to inverter, please make sure that the minimum insulation resistance to ground of PV string meets the minimum insulation impedance requirements ($R = \text{maximum input voltage} / 30\text{mA}$).
- Make sure that the DC cables are firmly connected without looseness after connection.
- Use a multimeter to measure the positive and negative electrodes of the DC cable and ensure that the positive and negative electrodes are correct without reverse connection, and the voltage is within the allowable range.




1




$$4\text{mm}^2 \leq S \leq 6\text{mm}^2$$




2



3



Make sure PV polarity is right,
PV voltage ≤ 800V for -LV type.
Others: PV voltage ≤ 1100V
The recommend PV voltage is 450V
for -LV type.
Others: The recommend PV voltage
is 800V



5.3.4 Connect AC cable

Danger:




- In order to ensure that the inverter and the grid can be safely disconnected from the grid in case of abnormal conditions, please connect the AC switch on the AC side of the inverter. Multiple inverters cannot be connected to one AC switch at the same time. Please select proper AC switch according to local regulations.
- Please prepare the AC output cable. See the figure for the recommended specification.
- If multi-core copper wire is selected, supporting crimping terminal shall be used for assembly. It is forbidden to directly press multi-core copper wire into the connector.

Warning:



- Residual current monitoring unit (RCMU) is integrated in the inverter. When the inverter detects leakage current greater than the allowable value, it will quickly disconnect from the grid.
- During wiring, the AC cable is completely matched with "L1", "L2", "L3", "N" and grounding port of AC terminal. If the cable is connected improperly, the equipment will be damaged.
- Make sure that the core is completely inserted into the terminal hole without exposure.
- Ensure that the cables are firmly connected, otherwise the terminal may be overheated and the equipment may be damaged when the equipment is operating.



1





Copper core:

| Model | C | D |
|------------------|----------------------|---------|
| ASN-(33~40)TL | 10-25mm ² | 18-25mm |
| ASN-(20~25)TL-LV | 10-25mm ² | 18-25mm |



2



3



4




5.3.5 Smart meter (optional)

There are two communication ports on the inverter, one is the USB COM1 port and the other is the 16-core COM2 port.

The USB COM1 port is used to connect the datalogger, and the 16-core COM2 port is used for multi-inverter RS485 daisy chain connection/electric meter communication interface.

The 16-core COM2 interface is defined as follows:



| Pin | Function | Description |
|-----|-----------|--|
| 1 | 485A1_1 | Interfaces for inverter cascading, grid dispatching, and external data acquisition(optional) |
| 2 | 485B1_1 | |
| 3 | 485A1_2 | |
| 4 | 485B1_2 | |
| 5 | 485 1 GND | |
| 6 | 485A2 | Interface for connecting an anti-backflow meter (optional) |
| 7 | 485B2 | |
| 8 | 485 2 GND | |

| Pin | Function | Description |
|-----|----------|----------------|
| 9 | DRM 1/5 | DRM (optional) |
| 10 | DRM 2/6 | |
| 11 | DRM 3/7 | |
| 12 | DRM 4/8 | |
| 13 | DRM 0 | |
| 14 | DRM_GND | |
| 15 | DRM_+5V | |
| 16 | DRM_GND | |



Watch out:


When connecting communication lines, please ensure that the wiring port definition completely matches the device, and the cable routing path should avoid interference sources, power lines, etc., so as not to affect signal reception.

ASN three phase inverter can meet the requirements of the zero export through one intelligent meter and three CTs. It can be set as single phase anti-backflow and three phase anti-backflow as required. Taking 40kW model as an example:


Single phase anti-backflow: three phase on grid power is independently adjusted. For example, if the load of L1/L2/L3 phase is 10kW/12kW/14kW respectively, then the output power of L1/L2/L3 will be 10kW/10kW/10kW respectively (the maximum single-phase on grid power of 40kW model is 13.3kW). The remaining power required will be purchased from the grid.

Three phase anti-backflow: sum regulation of three phase grid-connected power. If L1/L2/L3 phase load is 10kW/12kW/14kW respectively, then L1/L2/L3 output power will be 12kW/12kW/12kW respectively (40kW model single-phase maximum grid connection power is 13.3kW). The remaining power required will be purchased from the grid.

5.3.5.1 Anti-backflow wiring diagram (single inverter)



5.3.5.2 Anti-backflow wiring diagram (multi-inverter)





5.3.6 Datalogger connection (optional)



Watch out:

Detailed introduction of communication module can be obtained from the official website.

1. Open the COM1 port cover plate, assemble the datalogger and USB port together as shown in the figure, and tighten the datalogger.
2. The datalogger can support Wifi, 4G, LAN or SUNSPEC communication. Refer to the datalogger installation guide for detailed operation.



6 EQUIPMENT COMMISSIONING AND MAINTENANCE

6.1 Check before power-on

| Items | Checking items | Standard |
|-------|---------------------------------|---|
| 1 | Installation of inverter | The inverter shall be installed correctly, firmly and reliably |
| 2 | Cable arrangement | Cables shall be reasonably arranged and well protected, without damage |
| 3 | Datalogger | The data logger shall be installed correctly, firmly and reliably |
| 4 | Identifying | The safety signs and warning labels on the inverter are not blocked or damaged |
| 5 | Switch | "DC SWITCH" and all switches connected to the inverter are "OFF" |
| 6 | Cable connection | The AC output cable, DC input cable and grounding wire are connected correctly, firmly and reliably |
| 7 | Unused terminals and interfaces | Unused terminals and interfaces are protected with waterproof covers |
| 8 | Circuit breaker | Reasonable selection of AC and DC circuit breakers |
| 9 | Environmental requirements | Reasonable installation space, clean and tidy environment, no construction remains |

6.2 Power on the equipment

- Step 1: At the AC switch between the inverter and the power grid, measure the voltage at the power grid side with a multi-meter, and confirm that the power grid voltage is at the working power of the inverter Allowable pressure range.
- Step 2: Close the AC switch between inverter and utility/national grid.
- Step 3: Set "DC SWITCH" on the inverter to "ON".
- Step 4: Observe the inverter LED indicator and check the inverter operation status.

6.3 Set inverter parameters via APP



Watch out:

To ensure that the inverter works properly, please use the application program to complete the inverter parameter setting.

Scan the QR code below to download the application or log in following website to download this application:
<https://www.auxsolcloud.com>



Watch out:

Please also obtain the operating instructions of the communication rod from the official website, to set the contents more consistent with the application scenario.

6.4 Power off the equipment



Danger:

- When operating and maintaining the inverter, please turn off the inverter for treatment. Live operation of the equipment may cause damage to the inverter or electric shock.
- After the inverter is powered off, it will take a certain amount of time for internal components to discharge. Please wait until the equipment is fully discharged according to the required label time requirements.

- Step 1: Disconnect the AC switch between the inverter and the utility/national grid.
- Step 2: At the AC switch between the inverter and the utility/national grid, measure the voltage on the power grid side with a multi-meter to confirm that the power has been cut off.
- Step 3: Observe the inverter LED indicator, and confirm to enter standby.
- Step 4: Set "DC SWITCH" on inverter to "OFF".

6.5 Equipment removal



Danger:

- Make sure inverter is power off.
- Wear personal protective equipment when operating the inverter.

Step 1: Successively remove all electrical connections of inverter, including DC cable, AC cable, communication cable, communication module and protective earth wire.

Step 2: Remove the inverter from the back cladding.

Step 3: Remove the back cladding.

Step 4: Properly save the inverter and ensure that the storage conditions meet the requirements if the subsequent inverter is still put into use.

6.6 Equipment scrapping

If the inverter cannot be used anymore and needs to be scrapped, please dispose according to the electrical waste disposal requirements of the inverter country/region.

The inverter shall not be treated as household garbage.

6.7 Trouble shooting

Please troubleshoot according to the following methods. If the troubleshooting methods cannot help you, please contact the after-sales service center.

When contacting the after-sales service center, please collect the following information for quick solution.

1. Inverter information, such as serial number, software version, equipment installation time, fault occurrence time, fault occurrence frequency, etc.
2. Equipment installation environment, such as weather conditions, whether components are sheltered and whether there is shadow, etc. It is recommended to provide photos, videos and other documents to assist in analyzing problems.
3. Utility/National grid condition. If there is only indicator mode for inverter, fault information can be viewed through back platform/APP mode.

| Defect codes | Defect name | Fault cause | Solutions |
|--------------|--------------------------|---|---|
| 0101 | BUS software overvoltage | 1. Abnormal fluctuations in the power grid or load. 2. Weak illumination or abnormal changes in illumination. 3. Photovoltaic array configuration errors, excessive number of photovoltaic panels in series. 4. Poor photovoltaic ground insulation. | 1. If it happens accidentally, it may be caused by abnormal power grid, load or light for a short time. After the self-check is normal, the inverter will return to normal operation without manual intervention. 2. Check the series configuration of the corresponding photovoltaic array string to ensure that the open circuit voltage of the string is not higher than the maximum working voltage of the inverter. 3. Check the impedance of the photovoltaic string to the protection ground. If there is a short circuit, please rectify the short circuit point. |
| 0102 | BUS undervoltage | | |
| 0103 | BUS imbalance | | |
| 0104 | BUS hardware overvoltage | | |

| Defect codes | Defect name | Fault cause | Solutions |
|--------------|---------------------------------------|---|---|
| 0301 | R-phase inverter soft start timeout | 1. Abnormal power grid fluctuations. 2. Inverter sampling fault. 3. Wiring fault. | 1. If it occurs accidentally, it may be caused by the abnormal power grid or load for a short time. After the self-check is normal, the inverter will resume normal operation without manual intervention. 2. Disconnect the AC circuit breaker and photovoltaic input switch in turn, after 10 minutes, close the AC circuit breaker and photovoltaic input switch in turn to check whether the fault is still. 3. Please check whether the photovoltaic and AC cables are correctly connected according to the wiring requirements of the manual. |
| 0302 | S-phase inverter soft start timeout | | |
| 0303 | T-phase inverter soft start timeout | | |
| 0601 | R-phase inverter software overcurrent | 1. Abnormal fluctuations in the power grid or load. 2. Inverter sampling fault. | 1. If it occurs accidentally, it may be caused by a short-term abnormality of the power grid or load. After the self-check is normal, the inverter will return to normal operation without manual intervention. 2. If it occurs frequently, check whether the voltage frequency of the power grid is stable. If the power grid fluctuates greatly, enable the weak power grid mode and restart the inverter? |
| 0602 | S-phase inverter software overcurrent | | |
| 0603 | T-phase inverter software overcurrent | | |
| 0701 | R-phase inverter hardware overcurrent | | |
| 0702 | S-phase inverter hardware overcurrent | | |
| 0703 | T-phase inverter hardware overcurrent | | |
| 0704 | Bridge arm overcurrent | | |
| 0801 | R-phase inverter overvoltage | | |
| 0802 | S-phase inverter overvoltage | | |
| 0803 | T-phase inverter overvoltage | | |

| Defect codes | Defect name | Fault cause | Solutions |
|--------------|-----------------------------------|---|---|
| 1501 | Control board overtemperature | 1. Inverter installation location is not ventilated. 2. Ambient temperature is too high. | 1. Check whether the ventilation of the inverter installation position is good and whether the ambient temperature exceeds the maximum allowable ambient temperature range. 2. If there is no ventilation or the ambient temperature is too high, please improve its ventilation and heat dissipation. 3. Check whether the fan is working normally and whether the air duct is blocked or blocked by dust? |
| 1504 | Inverter module overtemperature | | |
| 1505 | Control board NTC not connected | Temperature detection circuit abnormality. | Disconnect the AC circuit breaker and photovoltaic input switch in turn, and then close the AC circuit breaker and photovoltaic input switch in turn after 10 minutes to check whether the fault persists? |
| 1508 | Inverter module NTC not connected | | |
| 1801 | PV1 overvoltage | Photovoltaic array configuration errors, excessive number of photovoltaic panels in series. | Check the series configuration of the corresponding photovoltaic array string to ensure that the open circuit voltage of the string is not higher than the maximum operating voltage of the inverter. ASN-20~25TL-LV≤800V ASN-33~40TL≤1100V |
| ... | ... | | |
| 1812 | PV12 overvoltage | | |
| 1901 | PV input software overcurrent | 1. Unreasonable component configuration. 2. Abnormal changes in illumination. | 1. Please check whether the AC connection line is correctly connected according to the wiring requirements of the manual. 2. Disconnect the AC circuit breaker, and photovoltaic input switch in turn. After 10 minutes, close the AC circuit breaker and photovoltaic input switch in turn to check whether the fault is still the same. |
| 2001 | PV input hardware overcurrent | | |
| 2101 | PV input arcing fault | 1. DC string connection terminals are not securely connected. 2. DC wiring is damaged. | Please check whether the component cables are properly connected according to the wiring requirements in the manual. |



| Defect codes | Defect name | Fault cause | Solutions |
|--------------|--|--|--|
| 2201 | PV1 reverse connection | DC string connections are reversed. | Turn off the AC circuit breaker and photovoltaic input switch in turn. After the inverter is turned off, adjust the DC ancestral positive and negative wiring, turn off the AC circuit breaker and photovoltaic input switch in turn to check whether the fault is still the same? |
| ... | ... | | |
| 2212 | PV12 reverse connection | | |
| 2301 | PV1 short circuit | Short circuit phenomenon in the DC string. | Disconnect the AC circuit breaker and photovoltaic input switch in turn, and close the AC circuit breaker and photovoltaic input switch in turn after 10 minutes to check whether the fault persists? |
| ... | ... | | |
| 2312 | PV12 short circuit | | |
| 2401 | Internal fan fault | 1. Abnormal fan power supply. 2. Mechanical failure (blocked rotation). 3. Fan aging and damage. | Check whether the fan is working properly, whether the air duct is blocked or blocked by dust. |
| 2402 | External fan fault | | |
| 2501 | First-order overvoltage (lowest voltage) | Power grid voltage exceeds or falls below the allowable range. | 1. If it happens accidentally, it may be that the power grid is abnormal for a short time. The inverter will return to normal operation after detecting that the power grid is normal, without manual intervention. 2. If it appears frequently, please check whether the grid voltage is within the allowable range. • If the grid voltage is outside the allowable range, contact your local electricity operator. • If the grid voltage is within the allowable range, it is necessary to modify the inverter after obtaining the consent of the local power operator, and the grid protection point. 3. If it cannot be recovered for a long time, please check whether the AC side circuit breaker and the output cable are connected normally. |
| 2502 | Second-order overvoltage | | |
| 2503 | Third-order overvoltage | | |
| 2504 | 10 minutes overvoltage | | |
| 2505 | First-order undervoltage | | |
| 2506 | Second-order undervoltage | | |
| 2507 | Third-order undervoltage | | |
| 2508 | Line voltage first-order overvoltage | | |

| Defect codes | Defect name | Fault cause | Solutions |
|--------------|--|--|--|
| 2509 | Line voltage second-order overvoltage | Power grid voltage exceeds or falls below the allowable range. | <p>1. If it happens accidentally, it may be that the power grid is abnormal for a short time. The inverter will return to normal operation after detecting that the power grid is normal, without manual intervention.</p> <p>2. If it appears frequently, please check whether the grid voltage is within the allowable range.</p> <ul style="list-style-type: none"> • If the grid voltage is outside the allowable range, contact your local electricity operator. • If the grid voltage is within the allowable range, it is necessary to modify the inverter after obtaining the consent of the local power operator, and the grid protection point. <p>3. If it cannot be recovered for a long time, please check whether the AC side circuit breaker and the output cable are connected normally.</p> |
| 2510 | Line voltage third-order overvoltage | | |
| 2511 | Line voltage first-order undervoltage | | |
| 2512 | Line voltage second-order undervoltage | | |
| 2513 | Line voltage third-order undervoltage | | |
| 2601 | First-order overfrequency (lowest frequency) | Power grid frequency exceeds or falls below the allowable range. | <p>1. If it happens accidentally, it may be that the power grid is abnormal for a short time. The inverter will return to normal operation after detecting that the power grid is normal, without manual intervention.</p> <p>2. If it appears frequently, please check whether the grid frequency is within the allowable range.</p> <ul style="list-style-type: none"> • If the grid frequency is outside the allowable range, contact the local electricity operator. • If the grid frequency is within the allowable range, it is necessary to modify the inverter grid protection point. <p>3. after obtaining the consent of the local power operator. If it cannot be recovered for a long time, please check whether the AC side circuit breaker and the output cable are properly connected.</p> |
| 2602 | Second-order overfrequency | | |
| 2603 | Third-order overfrequency | | |
| 2604 | First-order underfrequency | | |
| 2605 | Second-order underfrequency | | |
| 2606 | Third-order underfrequency | | |

| Defect codes | Defect name | Fault cause | Solutions |
|--------------|------------------------------|---|---|
| 2701 | Islanding fault | The power grid has been disconnected, and due to the presence of a load maintaining the grid voltage, grid-tied operation is stopped according to safety regulations to protect requirements. | Wait for the grid to return to normal after the machine will be connected again. |
| 2901 | ISO fault | <p>1. Photovoltaic strings short-circuit to the protective ground.</p> <p>2. The installation environment of the photovoltaic strings is chronically humid and the line insulation to the ground is poor.</p> | <p>1. Check the impedance of the photovoltaic string to the protection ground. It is normal that the resistance value is greater than 50kΩ. If the resistance value is less than 50kΩ, please check the short circuit point and rectify it.</p> <p>2. Check whether the protective earth wire of the inverter is connected correctly.</p> |
| 3001 | GFCI sensor fault | Leakage current sensor sampling abnormality. | Disconnect the AC circuit breaker and photovoltaic input switch in turn, and then close the AC circuit breaker and photovoltaic input switch in turn after 10 minutes to check whether the fault persists? |
| 3002 | GFCI fault | <p>1. Photovoltaic strings or AC lines short-circuit to the protective ground.</p> <p>2. Electrical equipment has leakage current.</p> <p>3. The machine installation environment is chronically humid and the line insulation to the ground is poor.</p> | <p>1. Confirm whether the insulation of photovoltaic string and AC line is normal?</p> <p>2. Check whether there is leakage current in electrical equipment?</p> |
| 3101 | Auxiliary source abnormality | Power circuit fault. | Disconnect the AC circuit breaker and photovoltaic input switch in turn. After removing the external communication cable, data acquisition rod and other equipment, close the AC circuit breaker and photovoltaic input switch in turn, check if the fault persists? |

| Defect codes | Defect name | Fault cause | Solutions |
|--------------|--------------------------------------|--|---|
| 3301 | Relay fault | 1. Relay abnormality (relay short circuit). 2. Control circuit abnormality. 3. Abnormal AC side wiring (possible virtual connection or short circuit). | 1. Please check whether the AC connection line is correctly connected according to the wiring requirements of the manual. 2. Disconnect the AC circuit breaker and photovoltaic input switch in turn. After 10 minutes, close the AC circuit breaker and photovoltaic input switch, check if the fault persists? |
| 4001 | Grid voltage detection inconsistency | Control circuit abnormality. | Disconnect the AC circuit breaker and photovoltaic input switch in turn, close the AC circuit breaker and photovoltaic input switch in turn after 10 minutes to check whether the fault still does not need to be handled. |
| 4002 | BUS voltage detection inconsistency | | |
| 4003 | GFCI detection inconsistency | | |
| 4201 | DRM shutdown | Responding to dispatch shutdown. | If you have any questions, please contact the installer. |
| 4202 | Command shutdown | | |
| 4203 | Remote Lockout | | |

6.8 Regular maintenance

| | |
|---|--|
|  | Danger: The machine must be kept power off state during maintenance. |
|  | Watch out: Regular maintenance can maintain the stability of inverter performance. |

| Content | Method | Cycle |
|-----------------------|---|-----------|
| System cleaning | Check the cooling fin and air inlet/outlet for foreign matter and dust. Especially the fan needs regular maintenance to prevent debris from blocking the fan and affecting the operation of the inverter. | half year |
| DC switch | Turn on and off the DC switch for 10 times continuously to ensure the normal function of DC switch. | one year |
| Electrical connection | Check whether the electrical connection is loose, whether the cable appearance is damaged and whether there is copper leakage. | half year |
| Tightness | Check whether the tightness of the equipment inlet hole meets the requirements. If the gap is too large or not sealed, it shall be re-closed. | one year |

7 TECHNICAL PARAMETER

| Model | ASN-33TL | ASN-36TL | ASN-40TL | ASN-20TL-LV | ASN-25TL-LV |
|---------------------------|-------------------------------|---------------|-----------------|-----------------|-----------------|
| Input DC | | | | | |
| Max.input power | 49.5kW | 54kW | 60kW | 30kW | 37.5kW |
| Max.input voltage | 1100V | 1100V | 1100V | 800V | 800V |
| Rated voltage | 600V | 600V | 600V | 360V | 360V |
| MPPT voltage range | 160-1000V | 160-1000V | 160-1000V | 160-800V | 160-800V |
| Start-up voltage | 180V | | | | |
| MPPT number | 3 | 3 | 4 | 4 | 4 |
| Max. input strings number | 5 | 5 | 6 | 6 | 6 |
| Max.input current | 40A/40A/20A | 40A/40A/20A | 40A/40A/20A/20A | 40A/40A/20A/20A | 40A/40A/20A/20A |
| Max.short circuit current | 50A/50A/25A | 50A/50A/25A | 50A/50A/25A/25A | 50A/50A/25A/25A | 50A/50A/25A/25A |
| Output AC | | | | | |
| Rated output power | 33kW | 36kW | 40kW | 20kW | 25kW |
| Max.apparent output power | 36.3kVA | 39.6kVA | 44kVA | 22kVA | 27.5kVA |
| Max.output power | 36.3kW | 39.6kW | 44kW | 22kW | 27.5kW |
| Rated grid voltage | 400V, 3/N /PE | 400V, 3/N /PE | 400V, 3/N /PE | 127/220V,3/N/PE | 127/220V,3/N/PE |
| Grid voltage range | 280V-520V | 280V-520V | 280V-520V | 160V-300V | 160V-300V |
| Rated grid frequency | 50Hz/60Hz | | | | |
| Rated grid output current | 47.6A | 52A | 57.7A | 52.5A | 65.6A |
| Max.output current | 52.4A | 57.2A | 63.5A | 57.7A | 72.2A |
| Power factor | 1 (0.8 leading...0.8 lagging) | | | | |
| THDi | <3% | | | | |
| Efficiency | | | | | |
| Max. efficiency | 98.60% | | | | |
| EU efficiency | 98.30% | 98.30% | 98.30% | 98.00% | 98.00% |
| MPPT efficiency | 99.80% | 99.80% | 99.80% | > 99% | > 99% |

| Protection | |
|---|----------|
| Integrated DC switch | Yes |
| DC rever-polarity protection | Yes |
| Anti-islanding protection | Yes |
| Short circuit protection | Yes |
| Output over currentprotection | Yes |
| DC Surge protection | Type II |
| AC Surge protection | Type II |
| Insulation impedance detection | Yes |
| Ground fault monitoring | Yes |
| Residual leakage current detection | Yes |
| Temperature protection | Yes |
| AC Over voltage protection | Yes |
| DC Over current protection | Yes |
| Strings monitoring | Optional |
| 24-hour load monitoring | Optional |
| Integrated AFCI (DC arc-fault circuit protection) | Optional |
| Integrated PID recovery | Optional |
| Antibackflow | Optional |

| General Data | |
|-----------------------------|---|
| Dimensions (W*H*D) | 568*443*228mm |
| Weight*[1] | 35Kg |
| Self consumption(night) | < 1W |
| Operating temperature range | -30 ... +60°C |
| Cooling concept | fan-cooling |
| Max. operation altitude | 4000m (Derating above 3000m) |
| Relative humidity | 0-100% |
| Safety/EMC standard | IEC/EN 62109-1/2, EN IEC61000-6-1/2/3/4, EN IEC 61000-3-11, EN 61000-3-12 |
| Ingress protection | IP66 |
| Topology structure | Transformerless |
| Grid connection stadard | NB/T32004, EN 50549-1 |
| Type of DC terminal | MC4 connector |
| Type of AC terminal | OT terminal |
| Display & Communication | |
| Display | LED+Bluetooth+APP (Optional:LCD) |
| Communication interface | RS485,Optional:WIFI,4G,LAN |

The product may be update in the future. The above parameters are for reference only. Please refer to the real thing.

*[1]:The weight parameters here are for reference only, and the actual weight shall prevail outside the box or official website.

